



**12 Lead
DELTA Connection
460V Only 60Hz**



L1	L2	L3
T1+T6+T7+T12	T2+T4+T8+T10	T3+T5+T9+T11

**12 Lead
PART WINDING DELTA Connection
460V Only 60Hz**



T1	T2	T3
1+6	2+4	3+5
T7	T8	T9
7+12	8+10	9+11